



Disassembling Nokia 3100b Microphone

Written By: Sterling Fuentes



INTRODUCTION

This guide show you how to access the phone's microphone, the component that receives sound when making a call.



TOOLS:

- [T6 Torx Screwdriver](#) (1)
-

Step 1 — battery



- Make sure your phone is turned off.

Step 2



- Press the button on the back of the phone and slide the back panel off.
- Remove the battery by pulling it from the phone.

Step 3 — Removing Nokia 3100b SIM Card



- Note the small metal frame that hold the SIM card into place.
- Gently pull back the tab and lift open the frame.

Step 4



- Retrieve your SIM card.

Step 5 — Microphone



- Press the black tabs to release the front cover from the phone.

Step 6



- Remove the front cover from the phone.
- Set the front cover, as indicated, aside.

Step 7




- Remove the screws as they are indicated in the order of the colors of the rainbow. (Red, Orange, Yellow, Green, Blue, Purple.)

Step 8




- Remove the screen assembly from the phone base.
- Set the screen assembly aside.

Step 9




- Note the location of the microphone.

Step 10



- Use tweezers to remove the microphone from the phone's base.

Step 11



- The microphone is now removed.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-25 03:23:31 PM.